



Lab and Pocket Thermometer, with Reset

OPERATING INSTRUCTIONS

NORMAL USAGE:

Insert stem at least 2 inches in fluids and 4 inches in gases to secure an accurate reading.

Lit#: #8INST.1204

SEMI-SOLID MATERIALS:

When inserting into semi-solid materials, such as frozen foods, soils, meat, fish, fruit, etc., hold stem firmly and insert slowly and carefully to avoid bending. Do not hold head when inserting, always hold stem.

www.reotemp.com

POINTER RESETTING:

Place wrench on hex nut on back of head. Place at least 4 inches of stem in an agitated fluid bath of known temperature. With fingers, securely grip and rotate the head until pointer indicates the known temperature.

San Diego, CA USA